

order-no.	Item	Description	design (color)	Price Incl. VAT
10010-000-31	100/1	Music stand	yellow green	€ 29,25
10010-000-33	100/1	Music stand	ocean blue	€ 29,25
11936-000-55	11936	Storage box for wagon	black	€ 65,05
11937-000-00	11937	Cover for wagon		€ 26,20
12185-000-55	12185	Laptop stand	black	€ 104,85
12297-000-57	12297	LED piano lamp	white	€ 91,25
13400-000-02	13400	Stacking chair	legs chrome, seatin	€ 172,85
13405-000-02	13405	Stacking chair	legs chrome, seatin	€ 179,65
13410-000-02	13410	Stacking chair	legs chrome, seatin	€ 211,65
13415-000-02	13415	Stacking chair	legs chrome, seatin	€ 219,45
13420-000-55	13420	Musician's chair	black	€ 242,75
13430-000-55	13430	Orchestra chair	black	€ 271,90
13440-000-55	13440	Orchestra chair	black	€ 670,00
13460-000-55	13460	Bass stool	black	€ 670,00
13470-000-55	13470	Chair for Percussion, Cello and Harp	black	€ 567,05
13480-000-55	13480	Chair for Kettledrums and Conductor's	black	€ 679,70
13490-000-55	13490	Chair cart	black	€ 145,65
13500-000-55	13500	Percussion table	black	€ 112,65
14005-000-02	14005	Backrest for »Gomezz«	chrome	€ 84,50
14060-000-55	14060	Stool	black imitation leath	€ 172,85
14061-000-55	14061	Pneumatic stool	black imitation leath	€ 205,85
14077-000-76	14077	Keyboard bench	pure white imitation	€ 130,10
14080-000-76	14080	Piano bench »Uplift«	pure white imitation	€ 355,40
14094-017-55	14094	Stage stool	black	€ 196,15
15229-000-55	15229	Clarinet stand	black	€ 19,40
15233-000-55	15233	English-Horn stand	black	€ 19,40
17540-013-00	17540	E-guitar stand	black with transluce	€ 42,35
17595-000-55	17595	Ukulele / Violin stand	black	€ 16,50
17605-000-00	17605	Four guitar stand »Roadie«	black with transluce	€ 151,45
18993-015-76	18993	Keyboard stand »Rick 20«	pure white	€ 84,10
19794-000-55	19794	Tablet PC wall mount	black	€ 42,15
24627-000-00	24627	Carrying case for base plate		€ 29,70
24628-000-00	24628	Carrying case for base plate		€ 28,75
24629-000-00	24629	Carrying case for base plate		€ 27,75
24645-000-55	24645	Lighting stand	black	€ 155,35
26703-000-56	26703	Base plate	structured black	€ 123,30
26704-000-56	26704	Base plate	structured black	€ 135,95
26705-000-56	26705	Base plate	structured black	€ 172,85
26734-000-55	26734	Speaker stand	black	€ 207,80
10001-000-00	10001	Spare part box		€ 150,20
10010-000-54	100/1	Music stand	blue	€ 29,25
10010-000-55	100/1	Music stand	black	€ 29,25
10010-000-57	100/1	Music stand	white	€ 29,25
10010-000-59	100/1	Music stand	red	€ 29,25
10010-000-60	100/1	Music stand	green	€ 29,25
10010-000-61	100/1	Music stand	yellow	€ 29,25
10010-000-65	100/1	Music stand	lilac	€ 29,25
10010-000-99	100/1	Music stand	rainbow	€ 29,25
10012-000-00	10012	Carrying case		€ 7,75
10040-000-55	10040	Music stand	black	€ 32,10
10050-000-11	100/5	Music stand	nickel-colored	€ 38,85

10050-000-54	100/5	Music stand	blue	€	38,85
10050-000-55	100/5	Music stand	black	€	38,85
10050-000-59	100/5	Music stand	red	€	38,85
10050-000-99	100/5	Music stand	rainbow	€	38,85
10052-000-55	10052	Music stand	black	€	42,70
10062-015-55	10062	Music stand »Robby Plus«	black	€	59,25
10065-000-11	10065	Music stand	nickel-colored	€	50,25
10065-000-55	10065	Music stand	black	€	49,00
10068-000-55	10068	School orchestra music stand	black	€	71,25
10100-013-11	101	Music stand	nickel-colored	€	22,80
10100-013-55	101	Music stand	black	€	22,80
10111-000-00	10111	Carrying case		€	6,60
10700-000-11	107	Music stand	nickel-colored	€	74,05
10700-000-55	107	Music stand	black	€	74,05
10711-000-00	10711	Carrying case		€	15,55
10810-000-55	10810	Music stand	black	€	87,00
10811-000-00	10811	Carrying case		€	19,60
11450-000-00	11450	Carrying case		€	45,65
11460-000-00	11460	Carrying case		€	28,55
11510-000-55	11510	Sheet music and document holder	black	€	48,55
11515-000-55	11515	Music holder	black	€	42,35
11520-000-55	115/2	Sheet music and document holder	black	€	33,00
11540-000-55	11540	Sheet music and document holder	black	€	75,35
11560-000-55	115/6	Magnet	black	€	4,10
11561-000-55	115/6	Magnet	black	€	4,45
11580-000-29	11580	Power magnet (2 pcs)	zinc-plated	€	5,65
11581-000-29	11581	Power magnet (10 pcs)	zinc-plated	€	19,05
11590-000-55	11590	Sheet music holder	black	€	8,75
11611-000-00	116/1	Wooden music stand	walnut	€	197,10
11616-000-00	116/1	Wooden music stand	beech	€	197,10
11617-000-00	116/1	Wooden music stand	cherrywood	€	197,10
11701-000-00	117	Wooden music stand	walnut	€	215,55
11706-000-00	117	Wooden music stand	beech	€	215,55
11707-000-00	117	Wooden music stand	cherrywood	€	215,55
11811-000-02	118/1	Orchestra music stand (set of 2)	chrome stand, waln	€	239,65
11811-050-02	118/1	Orchestra music stand	chrome stand, waln	€	121,35
11812-000-02	118/1	Orchestra music stand	chrome stand, black wooden desk	€	121,35
11812-000-55	118/1	Orchestra music stand	black stand, black w	€	115,95
11818-000-55	118/1	Orchestra music stand	black stand, black a	€	115,95
11819-500-02	118/1	Orchestra music stand	chrome stand, beec	€	122,15
11831-000-02	118/3	Orchestra music stand	chrome stand with v	€	140,80
11832-000-02	118/3	Orchestra music stand	chrome stand with t	€	137,90
11841-000-02	118/4	Orchestra music stand	chrome stand, waln	€	136,35
11842-000-02	118/4	Orchestra music stand	chrome stand, black	€	136,35
11865-000-55	11865	Orchestra music stand »Symphony«	black	€	77,50
11870-015-55	11870	Orchestra music stand	black	€	71,25
11888-000-55	11888	Orchestra music stand (set of 2)	black	€	228,55
11888-050-55	11888	Orchestra music stand	black	€	117,90
11899-000-55	11899	Orchestra music stand	black	€	83,90
11900-000-55	11900	Sound insulation stand	black	€	160,80
11930-000-55	11930	Orchestra music stand »Overture«	black	€	87,40

11935-000-55	11935	Wagon for orchestra music stands »Overture«	black	€	500,45
11940-000-55	11940	Orchestra music stand	black	€	53,85
11960-000-55	11960	Orchestra music stand	black	€	56,30
12120-000-55	12120	Orchestra music stand	black	€	67,75
12125-000-55	12125	Orchestra music stand	black	€	81,55
12140-000-55	12140	Universal table-top stand	black	€	64,65
12150-000-55	12150	Laptop stand	black	€	147,60
12152-000-55	12152	Mouse rest	black	€	49,35
12155-000-55	12155	Laptop stand	black	€	77,85
12179-000-55	12179	Music stand	black	€	65,25
12180-013-55	12180	Laptop stand	black	€	85,65
12210-000-55	12210	Bracket	black	€	12,05
12211-000-55	122a	Tray	walnut	€	34,35
12218-000-55	12218	Tray	black	€	37,65
12250-013-55	122e	Music stand light	black	€	36,25
12260-013-55	122/6	Double music stand light	black	€	61,35
12270-000-55	12270	Music stand light »Twin Head«	black	€	41,00
12275-000-55	12275	Double music stand light	black	€	95,15
12290-000-00	12290	Replacement bulb		€	6,00
12293-000-00	12293	LED replacement bulb		€	21,35
12295-000-55	12295	Music stand light	black	€	67,40
12296-000-55	12296	LED piano lamp	black	€	91,25
12297-000-40	12297	LED piano lamp	gold-colored	€	91,25
12297-000-55	12297	LED piano lamp	black	€	91,25
12297-000-63	12297	LED piano lamp	silver	€	91,25
12342-000-55	12342	Orchestra conductor stand	black	€	346,45
12383-000-81	12383	Promotional board (excl. Logo)	silver	€	35,35
12384-000-55	12384	Advertising panel for orchestra music desks	black	€	81,00
12386-000-81	12386	Lectern »Ovation Pro«	silver	€	1.223,85
12387-000-00	12387	Protective cover for lectern		€	169,55
12388-000-00	12388	Transportation case (hard case) for Lectern		€	1.093,50
12400-000-11	124	Table music stand	nickel-colored	€	18,45
12440-000-00	12440	Uni-Boy »Book« stand (set of 22)	4 color set	€	138,25
12440-012-54	12440	Uni-Boy »Book« stand (12 pcs)	blue	€	6,50
12440-012-59	12440	Uni-Boy »Book« stand (12 pcs)	red	€	6,50
12440-012-60	12440	Uni-Boy »Book« stand (12 pcs)	green	€	6,50
12440-012-61	12440	Uni-Boy »Book« stand (12 pcs)	yellow	€	6,50
12450-000-00	12450	Uni-Boy »Classic« stand (set of 22)	4 color set	€	138,25
12450-012-54	12450	Uni-Boy »Classic« stand (12 pcs)	blue	€	6,50
12450-012-59	12450	Uni-Boy »Classic« stand (12 pcs)	red	€	6,50
12450-012-60	12450	Uni-Boy »Classic« stand (12 pcs)	green	€	6,50
13020-000-55	13020	File holder	black	€	28,55
13100-000-55	131	Music holder	black	€	20,40
13322-000-01	13322	Multi rail	Nickel	€	10,35
13324-000-01	13324	Hoeksteun kort	Nickel	€	5,95
13326-000-01	13326	Hoeksteun Lang	Nickel	€	9,05
13330-000-01	133/3	Bass drum stand	nickel	€	106,40
13350-000-01	133/5	Woodblock holder	Nickel	€	33,65
13700-000-20	13700	Piano bench - wooden-frame	black matt finish	€	205,05
13701-000-21	13701	Piano bench - wooden-frame	black glossy finish	€	205,05
13710-000-22	13710	Piano bench - wooden-frame	white matt finish	€	205,05
13711-000-23	13711	Piano bench - wooden-frame	white glossy finish	€	205,05

13720-000-24	13720	Piano bench - wooden-frame	rosewood matt finish	€	205,05
13730-000-26	13730	Piano bench - wooden-frame	walnut matt finish	€	205,05
13740-000-28	13740	Piano bench - wooden-frame	cherry matt finish	€	205,05
13751-000-31	13751	Piano bench - wooden-frame	mahogany glossy fir	€	205,05
13800-100-00	13800	Seat cushion - velvet	black	€	34,20
13801-101-00	13801	Seat cushion - velvet	brown	€	34,20
13802-102-00	13802	Seat cushion - velvet	red	€	34,20
13803-103-00	13803	Seat cushion - velvet	hazelnut	€	34,20
13820-200-00	13820	Seat cushion - imitation leather	black	€	34,20
13821-201-00	13821	Seat cushion - imitation leather	brown	€	34,20
13824-204-00	13824	Seat cushion - imitation leather	white	€	34,20
13840-400-00	13840	Seat cushion - leather	black	€	87,95
13841-401-00	13841	Seat cushion - leather	brown	€	87,95
13900-100-20	13900	Piano bench	bench black matt fin	€	231,85
13901-100-21	13901	Piano bench	bench black glossy	€	231,85
13910-200-20	13910	Piano bench	bench black matt fin	€	231,85
13911-200-21	13911	Piano bench	bench black glossy	€	231,85
13950-100-21	13950	Piano bench with sheet music storage	bench black glossy	€	490,55
13951-200-21	13951	Piano bench with sheet music storage	bench black glossy	€	490,55
13980-200-21	13980	Piano bench with quilted seat cushion	bench black glossy	€	459,65
13981-400-21	13981	Piano bench with quilted seat cushion	bench black glossy	€	619,10
13990-200-21	13990	Piano bench	bench black glossy	€	408,00
13995-400-21	13995	Piano bench with quilted seat cushion	bench black glossy	€	884,35
14000-000-02	14000	Drummer's throne »Gomez«	chrome	€	261,40
14003-000-00	14003	Carrying case		€	50,70
14010-000-02	14010	Drummer's throne »Piccolino«	chrome	€	104,50
14015-000-55	14015	Drummer's throne	black imitation leath	€	135,75
14016-000-55	14016	Drummer's throne	black fabric	€	138,65
14020-000-02	14020	Drummer's throne »Picco«	chrome	€	110,50
14030-000-02	14030	Drummer's throne »Grande«	chrome	€	144,70
14032-000-55	14032	Backrest	black imitation leath	€	77,50
14033-000-55	14033	Backrest	black fabric	€	80,20
14041-000-00	14041	Carrying case		€	59,25
14044-000-55	14044	Stool	black fabric	€	202,95
14045-000-55	14045	Stool	black imitation leath	€	202,95
14046-000-55	14046	Pneumatic stool	black fabric	€	245,45
14047-000-55	14047	Pneumatic stool	black imitation leath	€	245,45
14051-000-55	14051	Footrest	black	€	41,35
14052-000-55	14052	Stool	black imitation leath	€	203,15
14053-000-55	14053	Stool	black fabric	€	205,25
14055-000-55	14055	Drummer's throne »Nick«	black imitation leath	€	173,05
14056-000-55	14056	Drummer's throne »Nick«	black fabric	€	178,10
14065-000-55	14065	Keyboard bench	black imitation leath	€	79,45
14066-000-55	14066	Keyboard bench	black fabric	€	81,35
14068-000-00	14068	Carrying case		€	45,45
14075-000-55	14075	Keyboard bench	black imitation leath	€	104,65
14076-000-55	14076	Keyboard bench	black fabric	€	104,65
14080-000-55	14080	Piano bench »Uplift«	black imitation leath	€	347,80
14081-000-55	14081	Piano bench »Uplift«	black fabric	€	347,80
14085-000-55	14085	Piano bench	black imitation leath	€	213,25
14086-000-55	14086	Piano bench	black fabric	€	213,25
14091-000-55	14091	Stage stool	black	€	399,65
14092-017-55	14092	Piano stool	black	€	201,75

14093-017-55	14093	Piano stool	black	€	<b>208,95</b>
14100-011-55	141	Double bass stand	black	€	<b>139,05</b>
14102-000-00	14102	Carrying case		€	<b>26,00</b>
14110-011-55	141/1	Cello stand	black	€	<b>139,05</b>
14130-000-95	14130	Cello Stand	cork	€	<b>83,10</b>
14160-000-55	14160	Stand for electric double bass	black	€	<b>139,05</b>
14300-000-55	14300	Saxophone stand	black	€	<b>27,45</b>
14301-000-55	14301	Peg holder	black	€	<b>8,15</b>
14303-000-00	14303	Carrying case		€	<b>21,15</b>
14315-000-55	14315	Soprano saxophone stand	black	€	<b>42,90</b>
14330-000-55	14330	Saxophone stand »Jazz«	black	€	<b>54,75</b>
14335-000-55	14335	Saxophone stand »Jazz«	black	€	<b>61,00</b>
14340-000-55	14340	Saxophone stand »Saxxy«	black	€	<b>47,95</b>
14350-000-55	14350	Saxophone stand »Saxxy«	black	€	<b>55,75</b>
14355-000-55	14355	Soprano saxophone stand »Saxxy«	black	€	<b>59,25</b>
14410-000-55	144/1	Baritone saxophone stand	black	€	<b>65,85</b>
14510-000-55	14510	Pick holder	black	€	<b>5,25</b>
14540-000-55	14540	Guitar capo	black	€	<b>12,45</b>
14545-000-55	14545	Guitar capo	black	€	<b>12,45</b>
14580-000-55	14580	Guitar playing-aid »Pohlmann«	black	€	<b>13,80</b>
14640-000-55	14640	Footrest	black	€	<b>12,60</b>
14670-014-11	14670	Footrest	nickel-colored	€	<b>13,50</b>
14670-014-54	14670	Footrest	blue	€	<b>13,50</b>
14670-014-55	14670	Footrest	black	€	<b>13,50</b>
14670-014-59	14670	Footrest	red	€	<b>13,50</b>
14760-000-55	14760	Guitar performer stand	black	€	<b>257,10</b>
14761-000-55	14761	Guitar performer stand	black	€	<b>257,10</b>
14910-013-55	149/1	Bass trombone stand	black	€	<b>121,95</b>
14920-012-55	149/2	Tenor horn stand	black	€	<b>102,55</b>
14922-000-00	14922	Carrying case		€	<b>24,85</b>
14930-011-55	149/3	Sousaphone stand	black	€	<b>165,65</b>
14940-000-55	14940	Tuba stand	black	€	<b>111,65</b>
14941-000-55	14941	Baritone stand	black	€	<b>111,65</b>
14942-000-00	14942	Carrying case		€	<b>21,35</b>
14945-000-55	14945	Stand for kingsize tuba	black	€	<b>196,70</b>
14950-000-55	14950	Tuba performer stand	black	€	<b>109,35</b>
14951-000-55	14951	Tuba performer stand	black	€	<b>111,45</b>
14952-000-55	14952	Tuba performer stand for children	black	€	<b>107,95</b>
14985-000-55	14985	Trombone stand	black	€	<b>34,00</b>
14990-000-55	149/9	Trombone stand	black	€	<b>51,05</b>
15010-011-55	150/1	Bassoon stand	black	€	<b>111,10</b>
15043-000-00	15043	Universal carrying case		€	<b>45,45</b>
15045-011-55	15045	Contrabassoon stand	black	€	<b>144,70</b>
15060-011-55	15060	Bass clarinet stand	black	€	<b>145,65</b>
15140-013-55	151/4	French horn stand	black	€	<b>111,85</b>
15210-000-55	152/1	Trumpet stand	black	€	<b>16,30</b>
15213-000-55	15213	Trumpet stand	black	€	<b>23,55</b>
15214-017-55	15214	Trumpet peg	black	€	<b>17,50</b>
15222-000-55	15222	Clarinet stand	black	€	<b>17,85</b>
15224-000-55	15224	Clarinet peg	black	€	<b>11,05</b>
15225-000-55	15225	Clarinet holder	black	€	<b>18,85</b>
15228-000-55	15228	Clarinet stand	black	€	<b>18,75</b>
15230-017-55	152/3	Flute stand	black	€	<b>15,80</b>

15232-000-55	15232	Flute stand	black	€	17,60
15235-000-55	15235	Flute holder	black	€	18,05
15240-000-55	15240	Flugelhorn stand	black	€	34,70
15244-017-55	15244	Flugelhorn peg	black	€	24,25
15250-017-55	152/5	Recorder stand	black	€	17,50
15252-000-55	15252	Recorder stand	black	€	18,05
15255-000-55	15255	Recorder holder	black	€	19,05
15260-017-55	152/6	Recorder stand	black	€	17,50
15262-000-55	15262	Recorder stand	black	€	18,05
15265-000-55	15265	Recorder holder	black	€	19,05
15270-000-55	15270	Trombone stand	black	€	82,55
15281-005-55	15281	Peg adapter	black	€	6,00
15290-000-55	15290	Soprano saxophone stand	black	€	30,70
15294-017-55	15294	Soprano saxophone peg	black	€	18,45
15520-000-55	15520	Violin stand	black	€	30,70
15530-000-55	15530	Violin stand	black	€	48,35
15550-000-98	15550	Violin/Ukulele display stand	wooden look	€	14,00
15580-000-55	15580	Violin holder	black	€	29,30
15590-000-55	15590	Ukulele holder	black	€	18,65
15700-000-55	157	Trumpet holder	black	€	15,90
15715-000-55	15715	Trumpet holder	black	€	21,15
15910-000-55	15910	Mute holder	black	€	27,20
15915-000-55	15915	Mute holder ring	black	€	10,70
16015-013-55	16015	Ashtray	black	€	25,05
16020-000-55	160/2	Drink holder	black	€	13,40
16022-000-55	16022	Universal drink holder	black	€	21,75
16060-000-55	16060	Sheet music clip (4 pcs.)	black	€	4,25
16060-100-55	16060	Sheet music clip (100 pcs)	black	€	85,85
16080-000-55	16080	Headphone holder	black	€	15,15
16085-000-55	16085	Headphone holder with table clamp	black	€	34,35
16090-000-55	16090	Headphone holder	black	€	17,65
16092-000-55	16092	Pencil holder	black	€	1,25
16094-000-55	16094	Pencil holder	black	€	1,25
16096-000-55	16096	Pencil holder	black	€	1,25
16099-000-55	16099	Holding magnet with pencil	black	€	4,10
16200-000-55	162	Guitar wall mount	black	€	13,00
16220-000-95	16220	Guitar wall mount	cork	€	16,30
16235-000-55	16235	Guitar wall mount	black	€	19,40
16240-000-55	16240	Guitar wall mount	black	€	16,70
16250-000-55	16250	Guitar wall mount	black	€	14,00
16255-000-55	16255	Guitar wall mount	black	€	27,95
16280-000-55	16280	Guitar wall mount	black	€	9,25
16280-000-95	16280	Guitar wall mount	cork	€	10,25
16280-014-00	16280	Guitar wall mount	white with transluce	€	10,25
16295-000-55	16295	Wall mount for electric guitar	black	€	66,20
16296-000-55	16296	Wall mount for acoustic guitar	black	€	66,20
16310-000-55	16310	Headphone wall holder	black	€	14,55
16320-000-55	16320	Universal holder	black	€	21,75
16410-000-11	164/1	Harmonica holder	nickel-colored	€	16,10
16415-000-55	16415	Harmonica holder	black	€	20,20
16416-000-55	16416	Harmonica holder	black	€	23,10
16420-000-55	164/2	Triangle holder	black	€	14,55
16450-000-55	16450	Drum stick holder	black	€	24,10

16580-000-55	16580	Violin wall holder	black	€	23,10
16590-000-55	16590	Ukulele wall mount	black	€	15,90
16600-000-01	166	Piano tuning lever	nickel	€	22,90
16610-000-01	166/1	Piano tuning lever	nickel	€	25,65
16700-000-01	167	Piano tuning lever set	nickel	€	87,20
16800-000-01	168	Tuning fork	nickel	€	4,45
16810-000-01	168/1	Tuning fork	nickel	€	5,85
16820-000-01	168/2	Tuning fork	nickel	€	8,75
17400-009-55	174	Accordion stand	black	€	452,50
17510-000-55	17510	Caster set for »Guardian« (4 pcs)	black	€	21,55
17513-016-00	17513	Three guitar stand »Guardian 3«	black with transluce	€	150,50
17513-016-55	17513	Three guitar stand »Guardian 3«	black	€	150,50
17515-016-00	17515	Five guitar stand »Guardian 5«	black with transluce	€	188,35
17515-016-55	17515	Five guitar stand »Guardian 5«	black	€	188,35
17525-016-00	17525	Five e-guitar stand »Guardian 5«	black with transluce	€	176,15
17534-016-00	17534	Four guitar stand »Guardian 3+1«	black with transluce	€	163,90
17540-013-55	17540	E-guitar stand	black	€	39,25
17540-013-95	17540	E-guitar stand	cork	€	42,35
17541-013-55	17541	A-guitar stand	black	€	39,25
17541-013-95	17541	A-guitar stand	cork	€	42,35
17550-000-35	17550	Guitar stand »Memphis Travel«	black anodized	€	33,40
17570-000-00	17570	E+A guitar stand »Duet«	black with transluce	€	26,00
17580-014-54	17580	A-guitar stand »Heli 2«	blue	€	21,50
17580-014-55	17580	A-guitar stand »Heli 2«	black	€	21,50
17580-014-59	17580	A-guitar stand »Heli 2«	red	€	21,50
17580-014-95	17580	A-guitar stand »Heli 2«	cork	€	25,40
17581-014-55	17581	E-guitar stand »Heli 2«	black	€	23,00
17581-014-95	17581	E-guitar stand »Heli 2«	cork	€	27,25
17590-000-55	17590	E-guitar stand »Wave 20«	black	€	14,95
17591-000-55	17591	A-guitar stand »Wave 10«	black	€	14,95
17620-000-55	17620	Guitar stand »Double«	black	€	67,40
17670-000-55	17670	Guitar stand »Memphis Pro«	black	€	50,70
17680-000-55	17680	Guitar stand »Memphis 10«	black	€	37,10
17685-000-55	17685	Guitar stand »Memphis 20«	black	€	31,85
17700-005-55	17700	Foldable base	black	€	10,70
17710-005-55	17710	Foldable base	black	€	16,50
17720-000-55	17720	Floor stand for spot lights	black	€	20,20
17725-000-55	17725	Floor stand for spot lights	black	€	20,20
17731-017-55	17731	English horn peg	black	€	15,55
17738-005-55	17738	Oboe peg	black	€	13,40
17741-017-55	17741	Clarinet peg	black	€	15,55
17782-005-55	17782	Recorder peg	black	€	10,50
17786-005-55	17786	Recorder peg	black	€	10,50
17788-005-55	17788	Flute peg	black	€	9,30
18020-000-55	18020	Oboe stand	black	€	23,30
18810-015-55	18810	Table-style keyboard stand »Omega«	black	€	160,20
18810-015-91	18810	Table-style keyboard stand »Omega«	ruby red	€	167,80
18813-016-55	18813	Stacker	black	€	105,45
18813-016-91	18813	Stacker	ruby red	€	110,50
18814-000-55	18814	Adapter	black	€	18,65
18815-000-55	18815	Laptop holder	black	€	134,00
18817-000-55	18817	Universal holder	black	€	28,55
18818-000-55	18818	Sheet music and concept holder	black	€	63,30

18819-000-55	18819	Controller keyboard tray	black	€	52,65
18825-000-55	18825	Equipment stand	black	€	135,75
18840-000-30	18840	Keyboard stand »Baby-Spider Pro«	anodized aluminum	€	319,65
18840-000-35	18840	Keyboard stand »Baby-Spider Pro«	black anodized	€	319,65
18846-000-00	18846	Carrying case		€	30,30
18851-000-00	18851	Carrying case		€	37,65
18853-000-55	18853	Adapter for »Spider Pro«	black	€	18,25
18860-000-30	18860	Keyboard stand »Spider Pro«	anodized aluminum	€	391,90
18860-000-35	18860	Keyboard stand »Spider Pro«	black anodized	€	391,90
18864-000-25	18864	Threaded bolt set for »Spider Pro«	black zinc-plated	€	12,45
18865-000-30	18865	Support arm set A	anodized aluminum	€	74,40
18865-000-35	18865	Support arm set A	black anodized	€	74,40
18866-000-30	18866	Support arm set B	anodized aluminum	€	74,40
18866-000-35	18866	Support arm set B	black anodized	€	74,40
18868-000-55	18868	Laptop rest	black	€	94,20
18868-000-81	18868	Laptop rest	silver	€	94,20
18872-300-55	18872	Extension rod	black	€	18,05
18873-300-55	18873	Universal holder for »Spider Pro«	black	€	32,25
18876-000-55	18876	Controller keyboard tray	black	€	47,20
18877-000-55	18877	Lectern desk for the »Spider Pro«	black	€	47,20
18878-000-55	18878	Sheet music and concept holder for »Spider Pro«	black	€	65,25
18880-000-55	18880	Table-style keyboard stand	black	€	144,50
18881-000-55	18881	Stacker A	black	€	63,30
18882-000-55	18882	Stacker B	black	€	72,25
18930-070-55	18930	Keyboard stand	black	€	56,90
18933-070-55	18933	Keyboard stand	black	€	56,90
18940-017-55	18940	KEYBOARD STAND	black	€	64,10
18941-000-55	18941	Stacker	black	€	71,65
18950-017-55	18950	Table-style keyboard stand	black	€	203,90
18952-000-55	18952	Stacker	black	€	70,30
18953-017-55	18953	Table-style stage piano stand	black	€	198,10
18954-000-55	18954	Adapter	black	€	18,05
18955-000-00	18955	Carrying case		€	48,55
18956-300-55	18956	Boom arm	black	€	51,25
18959-000-00	18959	Carrying case		€	68,35
18962-071-55	18962	Keyboard stand	black	€	35,75
18963-071-55	18963	Keyboard stand	black	€	54,75
18969-071-55	18969	Keyboard stand for kids	black	€	39,05
18990-015-55	18990	Keyboard stand »Rick«	black	€	79,45
18993-015-55	18993	Keyboard stand »Rick 20«	black	€	79,45
18995-017-55	18995	Keyboard stand	black	€	88,35
19500-011-55	19500	Speaker stand	black	€	132,05
19580-000-55	195/8	Mounting adapter	black	€	26,00
19654-000-55	19654	Flange adapter	black	€	4,65
19656-000-55	19656	Flange adapter	black	€	12,05
19665-000-55	19665	Flange adapter	black	€	23,70
19670-000-55	19670	Speaker tilt connector	black	€	42,55
19674-000-55	19674	Speaker tilt connector »Ring Lock«	black	€	70,10
19685-300-55	19685	Adapter for screens	black	€	27,40
19688-300-55	19688	Speaker mount	black	€	45,85
19695-100-55	19695	Universal joint	black	€	22,35
19695-300-55	19695	Universal joint	black	€	22,35
19705-000-00	19705	Shoulder bag for sheet music and tablets	black	€	83,90



19712-300-55	19712	iPad stand holder	black	€	36,10
19713-300-55	19713	iPad mini stand holder	black	€	36,10
19714-300-55	19714	iPad Air stand holder	black	€	36,10
19715-300-55	19715	Universal clamping holder	black	€	26,80
19717-300-55	19717	iPad Air 2 stand holder	black	€	36,10
19718-300-55	19718	iPad mini 4 stand holder	black	€	36,10
19722-000-55	19722	iPad holder	black	€	57,85
19723-000-55	19723	iPad mini holder	black	€	57,85
19724-000-55	19724	iPad Air holder	black	€	57,85
19727-000-55	19727	iPad Air 2 holder	black	€	57,85
19728-000-55	19728	iPad mini 4 holder	black	€	57,85
19732-000-55	19732	iPad wall mount	black	€	22,70
19733-000-55	19733	iPad mini wall mount	black	€	22,70
19734-000-55	19734	iPad Air wall mount	black	€	22,70
19737-000-55	19737	iPad Air 2 wall mount	black	€	22,70
19738-000-55	19738	iPad mini 4 wall mount	black	€	22,70
19740-000-55	19740	Tablet PC holder	black	€	70,45
19742-300-55	19742	Tablet PC stand holder	black	€	46,85
19745-015-55	19745	Smartphone holder	black	€	35,55
19752-000-55	19752	iPad table stand	black	€	51,25
19754-000-55	19754	iPad Air table stand	black	€	51,25
19757-000-55	19757	iPad Air 2 table stand	black	€	51,25
19758-000-55	19758	iPad mini 4 table stand	black	€	51,25
19760-000-55	19760	iPad mini table stand	black	€	51,25
19772-300-55	19772	iPad stand	black	€	70,10
19774-300-55	19774	iPad Air stand	black	€	70,10
19776-300-55	19776	Tablet PC stand	black	€	83,90
19777-300-55	19777	iPad Air 2 stand	black	€	70,10
19780-000-55	19780	Inclinable stand adapter	black	€	51,85
19790-316-55	19790	Tablet PC stand holder	black	€	43,70
19791-016-55	19791	Tablet PC holder	black	€	63,30
19792-016-55	19792	Tablet PC table stand	black	€	65,25
19793-316-55	19793	Tablet PC stand	black	€	79,80
19850-000-55	19850	Smartphone stand	black	€	13,80
19855-000-55	19855	Tablet-PC stand	black	€	20,95
19900-300-55	199	Microphone stand	black	€	53,40
20000-300-55	200	Microphone stand	black	€	86,60
20120-300-55	201/2	Microphone stand	black	€	50,10
20130-300-02	201A/2	Microphone stand	chrome	€	53,80
20130-300-55	201A/2	Microphone stand	black	€	51,25
20800-309-55	20800	Overhead microphone stand	black	€	110,90
20811-409-55	20811	Overhead microphone stand	black	€	267,60
21020-300-02	210/2	Microphone stand	chrome	€	73,60
21020-300-55	210/2	Microphone stand	black	€	68,35
21021-300-55	21021	Overhead microphone stand	black	€	101,55
21040-300-55	210/4	Overhead microphone stand	black	€	74,40
21060-300-02	210/6	Microphone stand	chrome	€	62,75
21060-300-55	210/6	Microphone stand	black	€	60,40
21060-300-87	21060	Microphone stand »Soft-Touch«	gray	€	64,65
21070-300-55	21070	Microphone stand	black	€	48,15
21080-300-02	210/8	Microphone stand	chrome	€	69,15
21080-300-55	210/8	Microphone stand	black	€	62,90
21080-300-87	21080	Microphone stand »Soft-Touch«	gray	€	70,70

21090-300-02	210/9	Microphone stand	chrome	€	77,70
21090-300-55	210/9	Microphone stand	black	€	72,00
21100-300-02	211	Boom arm	chrome	€	26,00
21100-300-55	211	Boom arm	black	€	24,85
21105-000-55	21105	Counter weight	black	€	20,95
21110-300-02	211/1	Boom arm	chrome	€	29,50
21110-300-55	211/1	Boom arm	black	€	28,35
21140-300-55	21140	Boom arm	black	€	25,05
21160-300-55	21160	Boom arm	black	€	18,65
21231-400-55	21231	Boom arm	black	€	131,45
21300-009-55	213	Speaker stand	black	€	240,20
21302-009-55	21302	Speaker stand	black	€	196,15
21310-000-55	213/1	Safety ring	black	€	24,45
21311-000-00	21311	Carrying case		€	36,90
21312-000-00	21312	Carrying case »Pro«		€	50,30
21315-000-00	21315	Carrying case		€	85,45
21326-000-55	21326	Adapter sleeve	black	€	2,25
21329-025-55	21329	Adapter	black	€	32,25
21330-900-55	213/3	Extension rod	black	€	39,60
21333-000-55	21333	Distance rod	black	€	20,40
21334-000-55	21334	Distance rod	black	€	28,95
21334-050-55	21334	Distance rod	black	€	28,95
21336-000-55	21336	Distance rod	black	€	57,85
21337-000-55	21337	Distance rod	black	€	58,05
21337-000-76	21337	Distance rod	pure white	€	69,90
21338-000-55	21338	Distance rod with hand crank	black	€	165,05
21339-000-55	21339	Distance rod with hand crank	black	€	169,55
21340-000-55	21340	Distance rod with hand crank and »Ring Lock«	black	€	205,25
21347-000-55	21347	Distance rod	black	€	50,10
21348-000-55	21348	Distance rod	black	€	47,75
21356-000-55	21356	Distance rod with pneumatic spring	black	€	179,05
21357-000-55	21357	Distance rod with pneumatic spring	black	€	183,30
21360-000-55	21360	Distance rod »Ring Lock«	black	€	76,15
21364-000-55	21364	Distance rod »Ring Lock«	black	€	59,25
21366-014-55	21366	Distance rod »Ring Lock«	black	€	115,95
21367-014-55	21367	Distance rod »Ring Lock«	black	€	84,10
21368-000-55	21368	Distance rod »Ring Lock«	black	€	95,95
21390-000-55	213/9	Crossbar	black	€	28,35
21393-070-55	21393	Crossbar	black	€	59,80
21394-000-55	21394	Screw fitting set (4 pcs)	black	€	22,15
21402-000-00	21402	Warning strip		€	13,20
21403-003-55	21403	Cable holder (3 pcs)	black	€	3,90
21404-000-55	21404	Cable clamp (2 pcs)	black	€	9,50
21411-400-55	21411	Overhead microphone stand	black	€	129,90
21420-000-55	21420	Speaker/Monitor stand	black	€	58,85
21421-000-00	21421	Carrying case		€	19,80
21422-000-00	21422	Carrying case		€	19,80
21430-500-55	21430	Overhead microphone stand	black	€	338,70
21431-300-55	21431	Mini boom arm	black	€	20,95
21435-009-55	21435	Speaker stand	black	€	81,05
21436-009-55	21436	Speaker stand	black	€	92,45
21441-000-55	21441	Adapter sleeve »Ring Lock«	black	€	55,75
21445-000-55	21445	Leveling leg for speaker stand	black	€	32,25

21445-000-59	21445	Leveling leg for speaker stand	red	€	32,25
21449-000-55	21449	Speaker stand package (2 pcs)	black	€	177,10
21450-000-30	21450	Speaker stand	anodized aluminum	€	88,35
21450-000-55	21450	Speaker stand	black	€	77,70
21455-009-55	21455	Speaker stand	black	€	138,05
21459-000-55	21459	Speaker stand package (2pcs)	black	€	166,80
21460-009-55	214/6	Speaker stand	black	€	142,95
21460-009-76	214/6	Speaker stand	pure white	€	156,15
21460-009-81	214/6	Speaker stand	silver	€	142,95
21463-000-55	21463	Speaker stand with pneumatic spring	black	€	225,65
21467-000-55	21467	Speaker stand »Ring Lock«	black	€	155,35
21500-000-29	215	Thread adapter	zinc-plated	€	2,60
21600-000-29	216	Thread adapter	zinc-plated	€	3,70
21700-000-29	217	Thread adapter	zinc-plated	€	1,65
21800-000-29	218	Thread adapter	zinc-plated	€	3,50
21900-000-29	219	Thread adapter	zinc-plated	€	3,30
21900-208-29	21900	Thread adapter	zinc-plated	€	7,40
21918-000-29	21918	Thread adapter	zinc-plated	€	7,75
21920-000-29	21920	Thread adapter	zinc-plated	€	6,40
21950-000-25	21950	Thread adapter	black	€	5,25
21980-000-29	21980	Thread adapter	zinc-plated	€	8,95
22110-300-55	221 a	Table flange	black	€	21,95
22130-300-55	221 c	Table flange	black	€	24,25
22140-300-55	221 d	Table flange	black	€	8,75
22160-300-55	22160	Ceiling stand	black	€	52,80
22300-300-01	223	Gooseneck	nickel	€	29,30
22300-300-55	223	Gooseneck	black	€	29,90
22400-300-01	224	Gooseneck	nickel	€	23,30
22400-300-55	224	Gooseneck	black	€	22,70
22500-300-55	225	Gooseneck	black	€	18,45
22600-300-55	226	Gooseneck	black	€	14,20
22700-300-55	227	Gooseneck	black	€	74,55
22800-300-55	228	Gooseneck	black	€	82,75
23010-300-55	230/1	Gooseneck	black	€	48,35
23020-000-55	230/2	Gooseneck	black	€	49,50
23030-300-55	230/3	Gooseneck	black	€	54,20
23040-000-55	230/4	Gooseneck	black	€	51,85
23105-300-55	23105	Table microphone stand	black	€	12,25
23110-316-55	231/1	Table microphone stand	black	€	9,30
23150-100-55	23150	Tabletop microphone stand	black	€	40,00
23150-300-55	23150	Tabletop microphone stand	black	€	40,00
23200-300-55	232	Table microphone stand	black	€	30,70
23220-300-55	23220	Table microphone stand	black	€	28,15
23230-300-55	23230	Table microphone stand	black	€	17,50
23250-300-55	23250	Design microphone table stand	black	€	33,60
23266-300-74	23266	Table microphone stand	gray	€	28,15
23300-300-55	233	Table- /Floor microphone stand	black	€	46,80
23320-300-55	23320	Microphone stand	black	€	45,45
23323-300-55	23323	Microphone stand	black	€	47,40
23325-300-55	23325	Table- /Floor microphone stand	black	€	41,95
23400-300-55	234	Table- /Floor microphone stand	black	€	64,65
23510-300-55	23510	Microphone bar	black	€	18,65
23550-300-55	23550	Microphone bar	black	€	13,40

23560-300-55	23560	Microphone bar	black	€	52,25
23600-300-55	236	Microphone bar	black	€	26,60
23700-300-55	237	Table clamp	black	€	11,25
23720-300-55	23720	Table clamp	black	€	26,60
23721-100-25	23721	Threaded bolt	black passivated	€	3,70
23721-300-25	23721	Threaded bolt	black passivated	€	3,70
23721-500-25	23721	Threaded bolt	black passivated	€	3,70
23750-000-55	23750	Microphone »Fishing Pole«	black	€	78,85
23760-000-55	23760	Microphone »Fishing Pole«	black	€	127,20
23770-000-55	23770	Microphone »Fishing Pole«	black	€	141,00
23780-000-55	23780	Microphone »Fishing Pole«	black	€	329,55
23785-000-55	23785	Microphone »Fishing Pole«	black	€	388,00
23790-000-55	23790	Microphone »Fishing Pole«	black	€	452,30
23800-300-55	238	Microphone holder	black	€	18,25
23850-311-55	23850	Microphone desk arm	black	€	116,50
23855-000-55	23855	Table flange	black	€	19,60
23860-311-55	23860	Microphone desk arm	black	€	214,60
23910-000-55	23910	Quick-Release Adapter for microphones	black	€	18,05
23956-000-55	23956	Popkiller	black	€	28,15
23966-000-55	23966	Popkiller	black	€	39,60
24010-314-55	240/1	Microphone arm	black	€	38,45
24030-300-55	24030	Microphone holder for drums	black	€	18,45
24035-300-55	24035	Microphone holder for drums	black	€	19,60
24050-311-55	240/5	Microphone holder	black	€	37,10
24105-000-55	24105	Speaker mounting fork	black	€	59,80
24110-000-55	24110	Speaker wall mount	black	€	88,15
24110-000-57	24110	Speaker wall mount	white	€	88,15
24116-000-55	24116	Connector plate	black	€	11,25
24120-000-55	24120	Speaker wall mount	black	€	173,40
24140-000-55	24140	Speaker wall mount	black	€	61,95
24150-000-55	24150	Speaker wall mount	black	€	90,90
24161-000-56	24161	Universal speaker wall mount	structured black	€	67,60
24161-000-66	24161	Universal speaker wall mount	structured white	€	67,60
24180-000-55	24180	Speaker wall mount	black	€	39,05
24180-000-57	24180	Speaker wall mount	white	€	39,05
24185-017-55	24185	Speaker wall/ ceiling mount	black	€	33,60
24185-317-55	24185	Speaker wall/ ceiling mount	black	€	33,60
24195-000-55	24195	Speaker wall/ ceiling mount	black	€	44,30
24281-000-55	24281	Screw-on adapter	black	€	33,60
24352-000-55	24352	Adapter panel 1	black	€	10,70
24352-000-57	24352	Adapter panel 1	white	€	10,70
24354-000-55	24354	Adapter panel 2	black	€	11,65
24354-000-57	24354	Adapter panel 2	white	€	11,65
24356-000-55	24356	Adapter panel 3	black	€	10,70
24356-000-57	24356	Adapter panel 3	white	€	10,70
24357-000-55	24357	Adapter panel 4	black	€	10,70
24357-000-57	24357	Adapter panel 4	white	€	10,70
24358-000-55	24358	Adapter panel 5	black	€	9,50
24358-000-57	24358	Adapter panel 5	white	€	9,50
24359-000-55	24359	Adapter panel 6	black	€	10,70
24359-000-57	24359	Adapter panel 6	white	€	10,70
24465-000-55	24465	Speaker wall mount	black	€	47,60
24465-000-57	24465	Speaker wall mount	white	€	47,60

24471-000-55	24471	Speaker wall mount	black	€	67,95
24471-000-57	24471	Speaker wall mount	white	€	67,95
24481-000-55	24481	Speaker wall mount	black	€	73,00
24481-000-57	24481	Speaker wall mount	white	€	73,00
24484-000-55	24484	Speaker wall mount	black	€	130,50
24496-000-55	24496	Speaker ceiling mount	black	€	102,55
24496-000-57	24496	Speaker ceiling mount	white	€	102,55
24516-000-00	24516	TV pin	blank	€	4,65
24518-000-29	24518	TV pin	zinc-plated	€	25,65
24519-000-29	24519	TV pin	zinc-plated	€	9,70
24521-000-55	24521	Reducer flange	black	€	22,35
24521-060-55	24521	Reducer flange	black	€	28,15
24521-070-55	24521	Reducer flange	black	€	36,90
24521-250-55	24521	Reducer flange	black	€	26,20
24521-300-55	24521	Reducer flange	black	€	24,45
24528-000-55	24528	Reducer flange	black	€	23,30
24610-009-55	246/1	Lighting/Speaker stand	black	€	340,25
24611-000-00	24611	Carrying case		€	53,80
24613-000-00	24613	Rigging		€	19,80
24620-000-35	24620	Lighting stand	black anodized	€	146,80
24621-000-55	24621	Screw fitting set (4 pcs)	black	€	14,20
24622-000-35	24622	Crossbar	black anodized	€	38,25
24624-000-55	24624	Lighting stand	black	€	267,40
24625-000-35	24625	Lighting stand	black anodized	€	114,95
24630-009-55	24630	Lighting stand	black	€	120,40
24637-000-55	24637	Side crossbar	black	€	40,60
24640-009-55	24640	Lighting stand	black	€	274,60
25200-300-55	252	Microphone stand	black	€	85,85
25400-300-55	25400	Microphone stand	black	€	29,00
25500-300-55	255	Microphone stand	black	€	85,25
25600-300-55	25600	Microphone stand	black	€	107,95
25680-300-55	25680	One hand microphone stand	black	€	73,40
25800-311-55	258	Table microphone clamp	black	€	54,35
25900-300-55	259	Microphone stand	black	€	74,40
25900-370-87	25900	Microphone stand »Soft-Touch«	gray	€	79,25
25910-300-55	259/1	Microphone stand	black	€	60,80
25910-300-87	25910	Microphone stand »Soft-Touch«	gray	€	63,90
25950-300-55	25950	Microphone stand »Rien«	black	€	66,20
25960-300-55	25960	Microphone stand	black	€	73,40
26000-300-02	260	Microphone stand	chrome	€	59,60
26000-300-55	260	Microphone stand	black	€	56,90
26004-000-00	26004	Knurled washer		€	5,45
26010-300-02	260/1	Microphone stand	chrome	€	48,15
26010-300-55	260/1	Microphone stand	black	€	41,95
26010-300-76	260/1	Microphone stand	pure white	€	61,15
26010-300-87	26010	Microphone stand »Soft-Touch«	gray	€	57,10
26019-000-00	26019	Carrying case		€	78,65
26045-300-55	26045	Stackable microphone stand	black	€	49,90
26075-300-55	26075	Stackable one-hand microphone stand	black	€	73,40
26085-300-55	26085	One hand microphone stand	black	€	70,70
26125-300-55	26125	Microphone stand	black	€	62,90
26145-300-55	26145	Microphone stand	black	€	102,55
26200-300-55	26200	One-hand microphone stand »Elegance«	black	€	120,20

26250-300-55	26250	One-hand microphone stand »Performance«	black	€	104,50
26700-000-56	26700	Base plate	structured black	€	77,30
26720-000-55	26720	Monitor stand	black	€	89,90
26735-000-55	26735	Speaker stand	black	€	129,70
26735-000-76	26735	Speaker stand	pure white	€	139,45
26736-000-55	26736	Distance rod	black	€	67,00
26737-000-55	26737	Speaker stand »Ring Lock«	black	€	161,75
26740-000-55	26740	Monitor stand	black	€	146,80
26747-000-55	26747	Projector tray	black	€	71,25
26750-000-55	26750	Speaker stand	black	€	114,95
26751-000-00	26751	Carrier bag for round base		€	24,45
26782-000-56	26782	Screen/Monitor stand	structured black	€	445,30
26783-000-56	26783	Screen/Monitor stand	structured black	€	465,90
26785-000-56	26785	Design monitor stand	structured black	€	275,75
26792-024-56	26792	Bearing plate	structured black	€	40,80
26792-032-56	26792	Bearing plate	structured black	€	51,25
26792-042-56	26792	Bearing plate	structured black	€	73,40
26793-000-56	26793	Adapter	black	€	34,20
26795-000-56	26795	Design monitor stand	structured black	€	289,75
27105-300-55	27105	Microphone stand	black	€	40,90
27195-300-55	27195	Microphone stand	black	€	54,95
28070-070-55	28070	Hackbrett stand	black	€	197,90
28075-000-55	28075	Mixer stand	black	€	194,20
28101-000-55	28101	Monitor stand	black	€	122,15
28130-011-55	28130	Amp stand	black	€	59,40
28200-000-55	28200	Rack wagon	black	€	294,20
28201-000-55	28201	Side cover	black	€	116,30
28210-070-55	28210	Panel	black	€	9,30
28220-070-55	28220	Panel	black	€	12,25
28230-070-55	28230	Panel	black	€	15,35
28240-070-55	28240	Panel	black	€	17,85
28306-000-55	28306	Panel	black	€	12,45
28308-000-55	28308	Panel	black	€	12,80
28312-000-55	28312	Panel	black	€	13,00
28410-000-55	28410	Single rack rail	black	€	7,95
28451-000-55	28451	Ventilation panel	black	€	11,05
28452-000-55	28452	Ventilation panel	black	€	14,75
28480-000-55	28480	Rackshelly	black	€	18,45
28481-000-55	28481	19" Rack shelf	black	€	31,85
28481-070-55	28481	19" Rack shelf	black	€	37,10
28482-000-55	28482	19" Rack shelf	black	€	34,00
28482-070-55	28482	19" Rack shelf	black	€	40,40
28483-000-55	28483	19" Rack shelf	black	€	37,50
28483-070-55	28483	19" Rack shelf	black	€	41,75
28635-000-55	28635	Double rack rail	black	€	27,20
28664-000-55	28664	19" Power box	black	€	155,55
28665-000-55	28665	19"-Power box	black	€	117,30
28668-000-55	28668	19" Power box	black	€	144,50
28670-000-55	28670	19" Power box	black	€	88,75
28675-000-55	28675	19" Power box	black	€	93,80
28676-000-55	28676	19" Power box	black	€	202,75
28680-000-55	286/8	Support bracket	black	€	9,70
28681-000-55	286/8	Support bracket	black	€	13,20

28687-000-55	286/8	Support bracket	black	€	14,75
29375-000-55	29375	Microphone table base	black	€	146,25
29376-000-55	29376	Microphone table base	black	€	104,85
29377-000-55	29377	Microphone table base	black	€	146,25
29390-000-55	29390	Microphone table base	black	€	111,65
30900-000-02	30900	Guitar capo	matt chrome	€	17,85
30910-000-02	30910	Guitar capo	matt chrome	€	17,85
30920-000-02	30920	Capo for ukuleles	matt chrome	€	17,85
37850-000-55	37850	RUKA Alu-stand leight weight	Black	€	31,05
37885-000-55	37885	RUKA Orchestra music stand	Black	€	52,70
40900-000-55	40900	Rack desk stand	black	€	103,10
42020-000-55	42020	Rack wagon	black	€	388,00
42021-000-55	42021	Extender brackets 19"	black	€	85,65
42040-000-55	42040	Mixer stand	black	€	142,95
44060-000-55	44060	Adapter for product holder	black	€	5,25
44110-000-55	441/1	Product support arm	black	€	22,55
44130-000-55	44130	Product holder	black	€	12,80
44132-000-55	44132	Product holder	black	€	12,05
44135-000-55	44135	Product holder	black	€	14,00
44137-000-55	44137	Product holder	black	€	13,20
44140-000-55	44140	Product holder for guitar	black	€	25,45
44155-000-55	44155	Tray	black	€	78,65
44160-000-55	44160	Product holder for guitar	black	€	14,00
44170-000-55	44170	Product holder for guitar	black	€	22,70
44180-000-55	44180	Product holder for guitar	black	€	19,40
44181-000-55	44181	Product holder for guitar	black	€	19,40
44185-000-55	44185	Product holder for acoustic guitar	black	€	65,65
44186-000-55	44186	Product holder for acoustic guitar	black	€	65,65
44192-000-55	44192	Universal holder	black	€	10,30
44195-000-55	44195	Product holder for headphone	black	€	17,10
44210-000-55	44210	Product holder for violin	black	€	23,10
44220-000-55	44220	Product holder for ukuleles	black	€	20,60
44240-000-55	44240	Product holder for saxophone	black	€	34,20
44250-000-55	44250	Product holder for trombone	black	€	30,50
44380-000-55	44380	Product holder for cymbal	black	€	18,25
44385-000-00	44385	Price tag holder		€	11,65
44420-000-00	44420	Leaflet holder		€	50,30
44500-000-55	44500	Product holder for microphone	black	€	17,65
48240-008-55	48240	Rack	black	€	200,20
48240-012-55	48240	Rack	black	€	243,90
48260-016-55	48260	Rack	black	€	383,15
48260-021-55	48260	Rack	black	€	414,60
49035-000-55	49035	Universal rack shelf	black	€	30,70
49070-000-55	49070	Sliding shelf	black	€	185,05
49122-072-55	491/2	Rackmount storage	black	€	157,10
49123-073-55	491/2	Rackmount storage	black	€	168,15
49124-074-55	491/2	Rackmount storage	black	€	182,75
49302-012-55	49302	Headphone holder	black	€	16,70
49411-000-55	494/1	Panel	black	€	6,80
49412-000-55	494/1	Panel	black	€	7,95
49413-000-55	494/1	Panel	black	€	8,95
49414-000-55	494/1	Panel	black	€	11,25
49421-000-55	494/2	Panel	black	€	9,90

49422-000-55	494/2	Panel	black	€	12,25
49423-000-55	494/2	Panel	black	€	14,20
49424-000-55	494/2	Panel	black	€	16,50
50500-000-55	50500	Trumpet work station	black	€	183,90
50510-000-55	50510	Clarinet peg-set	black	€	27,95
66350-070-55	66350	Connection sleeve	black	€	40,80
83845-000-00	83845	Guitar tool		€	34,75
85035-000-55	85035	Microphone clip	black	€	4,10
85035-500-55	85035	Microphone clip	black	€	3,70
85040-000-55	85040	Thread adapter	black	€	1,25
85045-217-55	85045	Thread adapter	black	€	1,25
85050-000-55	85050	Mikrofonklammer	black	€	4,10
85050-500-55	85050	Microphone clip	black	€	3,30
85055-000-55	85055	Microphone clip	black	€	4,25
85055-500-55	85055	Microphone clip	black	€	4,10
85060-000-55	85060	Microphone clip	black	€	4,45
85060-500-55	85060	Microphone clip	black	€	4,25
85070-000-55	85070	Microphone clip	black	€	4,85
85070-500-55	85070	Microphone clip	black	€	4,85
85610-000-55	85610	Reading light »Mighty Bright - Xtra Flex 2«	black	€	15,35
85620-000-55	85620	Music stand light »Mighty Bright - Xtra Flex«	black	€	12,15
85620-000-63	85620	Music stand light »Mighty Bright - Xtra Flex«	silver	€	12,60
85625-000-55	85625	Music stand light »Mighty Bright - Nu Flex«	black	€	30,10
85628-000-55	85628	USB cable	black	€	7,55
85635-000-55	85635	Music stand light »Mighty Bright - Wonder Flex«	black	€	25,85
85640-000-55	85640	Music stand light »Mighty Bright - Double Flex«	black	€	16,05
85650-000-55	85650	Music stand light »Mighty Bright - Duet 2«	black	€	23,05
85655-000-00	85655	Power unit	black	€	11,85
85660-000-55	85660	Music stand light »Mighty Bright - Pedal Board Light«	black	€	29,15
85665-000-55	85665	Music stand light »Mighty Bright - Hammer Head«	black	€	24,85
85670-000-55	85670	Music stand light »Mighty Bright - Orchestra Light«	black	€	62,15
85675-000-55	85675	Music stand light »Mighty Bright - Encore Light«	black	€	47,60
85682-000-63	85682	2 LED USB light »Mighty Bright«	silver	€	17,50
85695-000-55	85695	Magnet holder	black	€	6,60
85890-000-55	85890	Levelling adapter (2 pcs)	black	€	4,25

## DISCONTINUED ITEMS

## Follow-up Model

14042-000-55	Backrest black imitation leather	<b>14032-000-55</b>
14043-000-55	Backrest black fabric	<b>14033-000-55</b>
15214-000-55	Trumpet p black	<b>15214-017-55</b>
15230-016-55	Flute stanc black	<b>15230-017-55</b>
15244-000-55	Flugelhorn black	<b>15244-017-55</b>
15250-016-55	Recorder s black	<b>15250-017-55</b>
15260-016-55	Recorder s black	<b>15260-017-55</b>
15294-000-55	Soprano s black	<b>15294-017-55</b>
17731-005-55	English ho black	<b>17731-017-55</b>
17741-005-55	Clarinet pe black	<b>17741-017-55</b>
18950-000-55	Table-style black	<b>18950-017-55</b>
18953-000-55	Table-style black	<b>18953-017-55</b>
21431-000-55	Mini boom black	<b>21431-300-55</b>
14092-000-55	Piano stoo black	<b>14092-017-55</b>
14093-000-55	Piano stoo black	<b>14093-017-55</b>



14530-000-06	Guitar Capo	
14535-000-06	Guitar Capo	
16150-000-55	Guitar Holder	
26150-300-02	Microphone stand	
49010-000-55	Cable hanger	
49103-000-55	Rackmount lockbox	
49332-000-00	Plexiglass security cover	
49334-000-00	Plexiglass security cover	
85610-000-54	Reading light "Mighty bright" - Xtra Flex 2	
85610-000-60	Reading light "Mighty bright" - Xtra Flex 3	
85610-000-65	Reading light "Mighty bright" - Xtra Flex 4	
85681-000-63	1 LED USB light "Mighty Bright"	
44270-000-55	Product holder for trumpet	<b>44192-000-55 + 15214-017-55</b>
44280-000-55	Product holder for clarinet	<b>44192-000-55 + 15224-000-55</b>
44290-000-55	Product holder for flugel horn	<b>44192-000-55 + 15244-017-55</b>
44300-000-55	Product holder for soprano sax	<b>44192-000-55 + 15294-017-55</b>
44310-000-55	Product holder for recorder	<b>44192-000-55 + 17782-005-55</b>
44320-000-55	Product holder for recorder	<b>44192-000-55 + 17786-005-55</b>
44330-000-55	Product holder for flute	<b>44192-000-55 + 17788-005-55</b>